



445 450 445e 450e

Náhradní díly
Ersatzteile Pièces
détachées
Náhradní díly Repuestos
Reservdelar


A1**445., 450.
KRYT BRZDY ŘETĚZU A SPOJKY**

Strana 445., 450. A1		KRYT ŘETĚZOVÉ BRZDY A SPOJKY		
Poloha	Číslo položky	Množství	Poznámky	Sada
1	544 21 72-01	1		
2	504 54 28-01	1		1
3	537 04 30-01	1		1
4	544 08 30-01	1		1
5	503 85 52-01	1		1
6	503 46 59-01	1		1
7	544 08 29-01	1		1
8	503 89 08-02	1		1
9	503 89 29-01	1		1
10	735 31 08-20	1		1
11	537 39 29-01	1		1
12	537 34 72-01	1		1
13	537 39 26-01	1		1
14	544 35 75-01	1		1
15	503 21 70-10	10		1
16	525 35 43-01	1		1
17	544 25 05-01	1		1
18	537 34 78-01	1		




Strana 445, 450 A2		KRYT ŘETĚZOVÉ BRZDY A SPOJKY		
Poloha	Číslo položky	Množství	Poznámky	Sada
1	544 09 79-01	1		
2	735 31 08-20	1		1
3	537 28 66-01	1		1
4	540 06 33-01	1		1
5	537 01 74-01	1		1
6	503 89 08-02	1		1
7	503 46 59-01	1		1
8	503 85 52-01	1		1
9	544 08 29-01	1		1
10	503 21 70-10	7		1
11	544 08 30-01	1		1
12	537 04 30-01	1		1
13	503 89 29-01	1		1
14	537 39 70-01	1		1
15	537 07 94-02	1		1
16	740 48 07-02	1		1
17	503 23 00-63	1		1
18	544 37 68-01	1		1
19	503 22 00-01	1		

B 445, 450, 445e, 450e
ŠPOJKA A OLEJOVÉ
ČERPADLO




Strana B 445, 450, 445e, 450e			SPOJKA A OLEJOVÉ ČERPADLO	
Poloha	Číslo položky	Množství	Poznámky	Sada
1	537 11 05-03	1		
2	537 35 91-01	2		1
3	503 87 30-72	1		
4	503 25 52-01	1		3
5	503 93 18-01	1		
6	540 05 79-01	1		
7	537 15 48-01	1		
8	544 08 42-01	1		

C 445, 450, 445e, 450e
KRYT VÁLCE



Strana C 445, 450, 445e, 450e		KRYT VÁLCE		
Poloha	Číslo položky	Množství	Poznámky	Sada
1	544 34 83-03	1		
2	522 70 92-01	1		1
3	503 89 47-01	3		


D1 445, 450 STARTER



Strana 445, 450		STARTER		
D1				
Poloha	Článek	Množství	Poznámky	Sada
1	544 07 16-02	1		
2	544 07 15-01	1		1
3	537 28 32-01	1		1, 2
4	540 05 75-02	1		1
5	503 21 28-10	2		1
6	537 09 25-01	1		1
7	503 21 77-16	1		1
8	505 30 51-25	1		1
9	537 23 25-01	1		1
10	503 21 73-21	4		1
11	544 37 70-01	1	445	
11	544 37 70-02	1	450	
12	544 08 15-01	1		

D2

445., 450.
STARTER



Eleusqvarna

a-series
450

INT. PING.

X-TORQ

Eleusqvarna


a-series
445

INT. PING.


X-TORQ

Strana 445., 450. D2		STARTER		
Pozice	Článek	Množství	Poznámky	Sada
1	544 15 85-02	1		
2	544 15 84-01	1		1
3	537 28 32-01	1		1, 2
4	540 05 75-02	1		1
5	503 21 28-10	2		1
6	537 42 32-01	1		1
7	537 42 34-01	1		1
8	537 42 33-01	1		1
9	537 42 66-01	1		1
10	505 30 51-25	1		1
11	537 23 25-01	1		1
12	503 21 73-21	4		1
13	544 37 71-01	1	445.	
14	544 08 15-01	1		
15	544 37 71-02	1	450.	

E 445, 450, 445e, 450e
ZAPALOVACÍ SYSTÉM




Strana E 445, 450, 445e, 450e			ZAPALOVACÍ SYSTÉM	
Poloha	Článek	Množství	Poznámky	Sada
1	544 11 18-01	1		
2	537 24 56-01	2		1
3	501 81 99-03	2		1
4	503 23 00-42	2		1
5	529 27 11-01	2		1
6	503 22 04-01	1		
7	573 93 57-01	1		
8	510 10 15-01	1		
9	503 20 02-20	2		



7

A 544 97 20-01
Sada těsnění


Strana F 445, 450, 445e, 450e			TLUMIČ	
Poloha	Číslo položky	Množství	Poznámky	Sada
1	544 14 77-02	1		
2	503 86 36-01	1		1
3	544 08 31-04	1		
4	544 08 44-01	1		7
5	725 53 68-55	2		
6	724 12 87-59	1		1
7	544 97 20-01	1	Sada těsnění	

G**445, 450, 445e, 450e KARBURÁTOR A
VZDUCHOVÝ FILTR**

Strana G 445, 450, 445e, 450e		KARBURÁTOR A VZDUCHOVÝ FILTR		
Poloha	Číslo položky	Množství	Poznámky	Sada
1	544 08 23-01	1		
2	503 20 02-16	4		
3	544 08 38-01	1		
4	544 08 40-01	1		
5	503 21 07-25	2		
6	544 08 41-01	1		
7	544 14 82-01	1		
8	506 45 04-01	1	C1M-EL37B	
9	504 00 34-01	1		
10	544 23 14-01	1		9
11	503 93 66-01	1	odvzdušnění	
12	544 40 19-01	1	sací hadice	
13	544 12 97-01	1	zpětná hadice	
14	544 35 99-02	1		
15	503 21 07-50	2		
16	544 08 08-01	1	μ 80	
16	544 08 08-02	1	μ 44	
16	544 08 08-03	1	Felt	
17	502 08 10-01	1		7
18	502 08 11-01	1		7
19	502 08 08-01	1		7
20	502 08 12-01	1		7
21	503 48 18-01	1		7
22	537 38 52-01	1		7
23	502 08 09-01	1		7
24	735 58 30-00	1		14

H1

445, 445. VÁLEC
PISTU




A 544 97 20-01

Sada těsnění

Stránka 445, 445e H1		VÁLEC PÍST		
Poloha	Číslo položky	Množství	Poznámky	Sada
1	544 11 99-02	1		
2	544 08 84-03	1		1
3	537 40 11-01	1		1, 2
4	544 21 13-01	1		1, 2
5	503 25 63-01	1		1
6	544 10 87-01	1		13
7	544 10 92-01	1		13
8	503 20 05-27	4		
9	544 87 07-01	1		
10	503 23 51-11	1		
11	540 05 73-01	1		
12	503 55 22-01	1		1
13	544 97 20-01	1	Sada těsnění	


H2 450, 450e VÁLEC PIST




A 544 97 20-01

Sada těsnění

Stránka 450, 450e H2		VÁLEC PÍST		
Poloha	Číslo položky	Množství	Poznámky	Sada
1	544 11 98-02	1		
2	544 08 89-03	1		1
3	544 08 87-01	1		1, 2
4	544 21 13-01	1		1, 2
5	503 25 63-01	1		1
6	544 10 87-01	1		13
7	544 10 92-01	1		13
8	503 20 05-27	4		
9	544 87 07-01	1		
10	503 23 51-11	1		
11	540 05 73-01	1		
12	503 55 22-01	1		1
13	544 97 20-01	1	Sada těsnění	

J**445, 450, 445e, 450e
KLIKOVÝ HRÍDEL**


Strana J 445, 450, 445e, 450e		KLIKOVÝ HŘÍDEL		
Poloha	Článek	Množství	Poznámky	Sada
1	525 60 50-01	1		
2	544 06 20-01	2		1
3	544 01 38-01	2		1
4	503 25 63-01	1		

K445, 450, 445e, 450e
CRANKCASE

Strana K 445, 450, 445e, 450e		KOMORKA		
Poloha	Článek	Množství	Poznámky	Sada
1	537 43 82-01	1		
2	503 87 58-02	1		1
3	503 87 54-02	1		1
4	537 33 46-01	1		1
5	544 03 64-01	1		1
6	503 24 09-05	1		1
7	530 02 61-19	1		1
8	537 40 35-01	1		1
9	544 08 33-01	1		1
10	544 33 16-01	3		1
11	503 86 93-01	2		
12	544 11 12-01	1		
13	537 21 50-01	1		12
14	503 57 89-01	1		12
15	503 88 63-01	1		
16	544 31 62-01	2		
17	501 00 76-01	2		
18	503 21 51-03	1		
19	544 09 40-01	1		
20	503 21 70-10	1		
21	503 90 59-01	1		
22	503 21 75-20	2		
23	544 08 26-01	1		
24	503 89 24-01	1		
25	503 89 30-01	2		
26	503 43 65-01	1		

L


445, 450, 445e, 450e
PALIVOVÁ NÁDRŽ



Automaticky přeloženo pomocí DEEPL

Strana L 445, 450, 445e, 450e		PALIVOVÁ NÁDRŽ		
Poloha	Položka	Množství	Poznámky	Sada
1	537 43 79-01	1		
2	503 21 28-10	1		
3	720 18 25-20	1		
4	544 09 97-01	1		
5	544 09 99-01	1		
6	544 09 98-01	1		
7	504 12 22-01	1		
8	504 09 88-01	1		
9	544 12 86-01	1		
10	503 44 32-01	1		
11	544 12 97-01	1		
12	544 11 12-01	1		
13	537 21 50-01	1		12
14	503 57 89-01	1		12
15	544 37 50-01	1		
16	501 00 76-01	1		
17	544 10 12-01	2		1
18	721 12 63-39	1		1
19	537 35 95-01	1		1


M 445, 450, 445e, 450e
HANDLE



Stránka M 445, 450, 445e, 450e			HANDLE	
Poloha	Položka	Množství	Poznámky	Sada
1	544 08 39-01	1	rukojeť	
2	544 31 62-01	3	ŠROUB IHSCFT, PW6,3×2	
3	503 21 02-70	2	Šroub IHSCFT, PW6,3×1	
4	503 89 83-01	1	VIBRAČNÍ IZOLÁTOR, CYL	


N445, 450, 445e, 450e
KARBURÁTOR**ZAMA C1M-EL37B**

37 B GND-81



Automaticky přeloženo pomocí DEEPL


Strana N 445, 450, 445e, 450e		KARBURÁTOR		
Poloha	Položka	Množství	Poznámky	Sada
1	506 45 04-01	1		
2	502 07 82-01	1		1
3	502 07 83-01	1		1
4	502 07 84-01	1		1
5	502 07 86-01	1		1
6	502 07 87-01	1		1
7	503 47 90-01	1		1
8	503 47 96-01	1		1
9	503 47 97-01	1		1
10	503 48 00-01	1		1
11	503 48 01-01	1		1
12	503 48 05-01	4		1
13	503 48 11-01	1		1
14	503 48 18-01	2		1
15	503 53 56-01	2		1
16	503 53 57-01	1		1
17	503 66 59-01	1		1
18	537 02 01-01	1		1, 37
19	537 38 31-01	1		1, 37
20	502 07 89-01	1		1
21	537 38 33-01	1		1
22	537 38 34-01	1		1
23	537 38 37-01	1		1
24	544 23 77-01	1		1
25	502 07 90-01	1		1, 37
26	502 07 91-01	1		1
27	505 10 17-01	1		1
28	502 07 94-01	1		1
29	502 07 95-01	1		1
30	502 24 77-01	1		1
31	502 07 98-01	1		1
32	537 38 36-01	1		1, 37
33	502 08 17-01	1		1
34	502 07 99-01	1		1
35	502 08 00-01	1		1
36	502 08 01-01	1		1
37	502 08 02-01	1	B = Sada těsnění	
38	544 11 95-01	1		1




Stránka P 445, 450, 445e, 450e			PŘÍSLUŠENSTVÍ	
Poloha	Číslo položky	Množství	Poznámky	Sada
1	5035585-04	1		



445
ZIMNÍ SADA



445e, 450e
ZIMNÍ SADA



Stránka Q 445, 445e, 450e			ZIMNÍ SADA	
Pozice	Položka	Množství	Poznámky	Sada
1	544 46 45-01	1	Zimní sada	
2	503 21 70-16	2		1
3	544 46 45-02	1	Zimní sada e-series	
4	503 21 70-16	2		3